



Maintenance of Stainless-Steel Finishes

Polished #8 and brushed # 4 finishes on stainless steel (alloy 304) are some of the most durable and easiest finishes to maintain.

PRL GLASS recommends a soft, clean cloth and a foam-type spray glass cleaner on the soft cloth, wipe the stainless-steel part directionally parallel to its length.

This method applies to both polished & brushed finishes.

Note: Do not use circular motions when cleaning stainless steel, especially on polished finishes, as doing so leaves fine polish lines on the surface. Do not use steel wool to clean brushed stainless steel. Steel wool leaves small pieces of wool in the brushed grooves. These pieces of wool will rust, thus the impression that the stainless steel is rusting, which is impossible.